Maintenance planning

Maintenance chart

Change fluid							Drain fluid					
Replace						Cleaning						
Check						Γ	Т	est				
Grease)											
Maintenance action								Page no.				
Break-in period												
Grease points (Bucket)	х							6-15				
Cab protection (ROPS and FOPS)		х						6-15				
Tightening torques		х						6-15				
Track shoe bolt torque		х						6-15				
Hydraulic oil return filter			x					6-15				
Pilot line filter			х					6-15				
Swing reduction unit oil				x				6-15				
Travel reduction units oil			2	x				6-15				
Every 10 hours												
Engine oil level		х						6-16				
Engine coolant level		х						6-17				
Hydraulic oil level		х						6-18				
Fuel tank				2	x			6-19				
Every 50 hours												
Air conditioner filters)	<		6-20				
Every 250 h	ou	rs		-		_						
Grease points (Bucket)	х							6-22				
Swing reduction unit oil		х						6-23				
Travel reduction units oil		х						6-24				
Engine primary air filter)	<		6-25				
Batteries		х						6-28				
Hydraulic oil tank				2	x			6-31				
Tightening torques		х						6-32				
Track shoe bolt torque		х						6-33				
Track rollers and idler wheels		х						6-34				
Cab protection (ROPS and FOPS)		х						6-34				
Every 500 h	ou	rs			-	-	-	-				
Turntable bearing	х							6-35				
Radiator and coolers)	<		6-38				
Every 1000	hou	irs	_	_	-	-		1				
Engine oil and filter			_	x				6-39				
Fuel pre-filter		_	x					6-41				
Fuel filter			x					6-42				
DEF/AdBlue® tank vent filter		_	x	\downarrow			\downarrow	6-43				
Grease points (Boom and arm)	Х		_	4		+	_	6-44				
Hydraulic tank breather filter		_	x				1	6-47				
Engine air filters			x					6-48				
Hydraulic fluid analysis		х				⊥		6-51				
Swing reduction unit oil		Ш)	x				6-52				
Alternator		х					_	6-54				
Starter motor		Х	1	1				6-54				
Every 1500	hou		_	_	-	-	_	La				
Blow-by filter			x				1	6-55				
Engine belts			X					6-57				
Every 2000	hou	irs				-,	-					
Travel reduction units oil			2	x				6-58				

Change fluid						Drain fluid						
Replace							Cleaning					
Check							Т	est				
Grease												
Maintenance action								Page no.				
Hydraulic oil suction filter					х			6-59				
Hydraulic oil return filter		2	x					6-60				
Pilot line filter		2	x					6-61				
Air conditioner filters		2	x					6-62				
Swing reduction gear	Х							6-62				
Engine valve rocker clearance adjustment		х						6-62				
Every 4000 hours												
Engine coolant)	(6-63				
Diesel Exhaust Fluid (DEF)/AdBlue® tank suction filter -					х	Ŀ		6-67				
Cleaning												
DEF/AdBlue® supply module filter		2	x					6-69				
Pump outlet hoses		х						6-70				
Hydraulic hoses		х						6-70				
Every 5000 hours												
Hydraulic oil and filters			2	۲				6-71				
When necessary												
Track tension		х						6-74				
Fuel tank strainer					Х			6-77				
Engine oil analisys						х		6-77				
Gas spring inspection		х						6-78				
Bulb replacement		2	x					6-79				
Bucket teeth			x					6-82				
Cylinders		х						6-84				
Plastic and resin parts					Х			6-84				
Air-conditioning system		х						6-85				
DEF/AdBlue® tank drain				>	<			6-87				