## **NEW HOLLAND**

NEW HOLLAND





## MODELS

## TSA 120 HIGH CLEADANCE

MODELS	TS6.120 HIGH CLEARANCE
Engine	
Make	IVECO F4CE9484J
No. Cylinders / Aspiration	4 / Turbocharged and Intercooled
Number of valves per cylinder	4.5
Capacity (I) Rated Speed	4.5
Rated Engine Power ISO TR14396 [kW/hp]	88 / 118
PTO Power at Rated Speed [kW/hp]	72.9 / 97.8
Max Torque @ 1300erpm (Nm)	515 @1250
Fuel capacity (I)	150
Torque Rise (%)	35
Emission legislation level	Tier III
Transmission	12F x 12R ( 8 x 8 + creeper)
Base Power Shuttle	
Minimum / Maximum speed (kph)	0.26 - 30
Option	Dual power - (8 x 8 + creeper + Dual power)
Number of Gears forward / reverse	24 x 12
Dual power change	Right Hand console switch operated
Minimum / Maximum speed (kph)	0.21 - 30
Transmission Clutch Type	Wet clutch
Rear Axle Spur Gear (drop box)	
Max Permissible Load - std (kg)	4990
Min / Max. Track Settings (mm)	1829-2134
Diff Lock Engagement	Electro Hydraulic
Front Axle (4WD)	
Class 3	•
Maximum Capacity (kg)	4100
Min / Max. Track Settings (mm)	1829-2134 Flagter Lladerulia
Automatic 4WD Engagement Diff Lock Engagement	Electro Hydraulic Electro Hydraulic
Hydraulic System	
System type	Gear - Open Centre
High Pressure circuit - Remotes / Lift pump capacity (I/min)	49
Low Pressure circuit - Steering / Lubrication pump capacity (I/min)	34
Auxiliary Pump to supply hitch and remote valves (I/min)	34
Auxiliary Remote Control Valves	
No. of Rear Auxiliary Remote Valves Standard Remote valve #1	4 Raise, Neutral, Lower (with detent kick out)
Remote valve #2	Raise, Neutral, Lower and Float (with detent kick out)
Remote valve #3	Raise, Neutral, Lower and Float (with detent kick out)
Remote valve #4	Raise, Neutral, Lower and Float (with detent kick out)
Colour Code for controls and couplers	•
Connect and disconnect couplers under pressure	•
Max flow available @ one remote	83lpm @ rated engine speed & pressure
Rear Linkage Category Cat I/II	•
MDC - Mechanical Draft Control	
Linkage attachment type	Fixed ball ends
Stabilisers	Telescopic
Right hand turn buckle levelling arm	•
Swinging Drawbar (27mm hole with clevis)	•
Rear Linkage - Lift Capacity Lift capacity - Maximum (kg) at end of lower link	2040
Lift capacity - Maximum (kg) at end of lower link Lift capacity - 610mm behind ball ends	<u>3640</u> 2804
(PTO) Power Take Off system	2007
PTO Engagement	Fully independent wet clutch
PTO Speeds	540 / 1000
Engine Speed at 540 rpm	1900
Engine Speed at 1000 rpm	2050
Operator Environment - Cab	
Deluxe Air suspension seat with seat belt Tilt and telescoping steering wheel	•
Air conditioning	
Operator Environment - ROPS	-
Deluxe Mechanical suspension seat with seat belt	•
Tilt and telescoping steering wheel	•
	•
Foldable ROPS frame	
Foldable ROPS frame Dimensions & Weight	
Foldable ROPS frame Dimensions & Weight Wheelbase (mm)	2520
Foldable ROPS frame           Dimensions & Weight           Wheelbase         (mm)           Overall length to end of link ends         (mm)	2520 4110
Foldable ROPS frame           Dimensions & Weight           Wheelbase         (mm)           Overall length to end of link ends         (mm)           Overall Width - Rear tyre Outside to Outside - 64* track setting         (mm)	2520 4110 2385
Foldable ROPS frame         Dimensions & Weight         Wheelbase       (mm)         Overall length to end of link ends       (mm)         Overall Width - Rear tyre Outside to Outside - 64* track setting       (mm)         Ground clearance under front axle       (mm)         Ground clearance under drawbar       (mm)	2520 4110 2385 637 708
Foldable ROPS frame         Dimensions & Weight         Wheelbase       (mm)         Overall length to end of link ends       (mm)         Overall Width - Rear tyre Outside to Outside - 64* track setting       (mm)         Ground clearance under front axle       (mm)	2520 4110 2385 637 708 3077

Standard

## AT YOUR OWN DEALER



YOUR SUCCESS - OUR SPECIALTY

Visit our web site at: www.newholland.com - tel: +61 2 9673 7777 31-53 Kurrajong Road, St Marys NSW 2760



Safety begins with a thorough understanding of the equipment. Always make sure you and your operators read the Operator's Manual before using the equipment. Pay close attention to all safety and operating decals and never operate machinery without all shields, protective devices and structures in place.

The data indicated in this folder are approximate. The models described here can be subjected to modifications without any notice by the manufacturer. The drawings and photos may refer to equipment that is either optional or intended for other countries. Please apply to our Sales Network for any further information. Published by New Holland Brand Communications. - Printed in Australia - 14NHTS6AUS 02/15